

# BB ALERT® ACTIVE

## QUICK INSTALLATION GUIDE



### Installation

The BB ALERT® ACTIVE monitor should be used overnight, starting between 6 and 9 o'clock in the evening. You should only prepare the BB ALERT® ACTIVE monitor immediately before use. Open the unit by gently lifting on the insulated cover while holding the base, and remove any protective cardboard packaging. Open the protective plastic wrapper on one activator and remove the paper sachet. Place the sachet into the center of the BB ALERT® ACTIVE monitor's base, and replace the insulated cover. The BB ALERT® ACTIVE monitor is now ready for use.

Use the BB ALERT® ACTIVE carpet base to secure the monitor when used on carpeted surfaces. Remove the paper cover from the lower adhesive pad of the carpet base and position it where the monitor is to be used, then remove the paper cover from the upper adhesive pad. Attach the BB ALERT® ACTIVE monitor base to the carpet base by pressing gently on the corners until it snaps, then install the activator sachet and insulated cover.

The BB ALERT® ACTIVE monitor should be placed as close to the normal feeding site (usually the bed) as is practical. It should be placed where it will not be disturbed, such as on the floor next to one of the bed legs, preferably at the head end of the bed. If the area where you are installing the BB ALERT® monitor has been recently treated with pesticides, you should clean the surfaces immediately surrounding the area very thoroughly prior to installation.

You should use the BB ALERT® ACTIVE monitor for two nights over a three or five day period to optimize the results (for example, monitoring on Tuesday and Thursday nights). You may continue to use the same BB ALERT® ACTIVE monitor throughout the period (using a fresh activator sachet each night), unless the insect detecting surface becomes heavily congested with insects.

Monitoring frequency depends on the sensitivity of the location and the potential for Bed Bugs to enter the structure. For high incidence locations and sensitive structures it is recommended that a two day monitoring is performed every month.

### Inspection

Remove the insulated cover, the activator sachet, and the monitor base (when used with the carpet base) to inspect the BB ALERT® ACTIVE monitor. The spent activator sachet may be placed in the household trash. Bed Bugs detected by the BB ALERT® ACTIVE monitor will be seen on the insect detecting surfaces of the monitor and the carpet base. The BB ALERT® ACTIVE monitor may contain both adult and nymph Bed Bugs. When evidence of Bed Bug activity is found on the BB ALERT® ACTIVE detection surfaces, it is recommended that the monitor containing the insects is saved for identification by a pest control professional or other qualified person. You should not assume that removing Bed Bugs with the BB ALERT® ACTIVE monitor has eliminated the Bed Bug problem.



For more details on placement and inspection of the BB ALERT® ACTIVE Bed Bug monitor, see the full installation guide available from: [www.BedBugsAlert.com/manuals](http://www.BedBugsAlert.com/manuals)

**MIDMOS**

MidMos is a subsidiary of Brandenburg UK Ltd